


NO. 0856 CORE soft shell jacket | women



Description (measured in cm)	S	M	L	XL	2XL	3XL
A: ½ Chest width	48	51	54	57	60	63
E: Front length from high point shoulder	65	67	69	71	73	75
H: Shoulder to shoulder	39.5	41	42.5	44	45.5	47
K: Sleeve length - long	63	64	65	66	67	68
L: ½ upper arm width	18.5	19.5	20.5	21.5	22.5	23.5

How to measure



Tolerance in cm

A	E	H	K	L
1.5	1.5	1.5	1.5	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not after washing. We reserve the right to make mistakes and omissions in the chart. You are always welcome to contact us for further guidance on using our product measurement chart at support@id.dk or tel: +45 97492144